



RADIAN[™] **TRIPOD LEVELING HEAD**

PRODUCT MANUAL



To help stabilize the tripod in windy conditions, hang a weight from the Counterweight Hook.

Attaching/Removing the Leveling Head

To mount the leveling head to the tripod:

1. Lift the Quick-Release Locking Latch on the tripod.
2. Press and hold the Quick-Release Button and fully seat leveling head into the tripod. Once seated, the leveling head can be oriented in any direction.
3. Rotate the Quick-Release Locking Latch down to the locked position.
4. To remove the leveling head, follow these steps in reverse order.

NOTE: If needed, the locking latch can be repositioned by shifting the latch to the left and rotating the latch up/down to reposition.

Press the Quick-Release Button on the tripod to seat the leveling head.



BASIC ADJUSTMENTS

Tilt Action

The leveling head's tilt can be adjusted by unlocking the leveling head. This allows you to position your optic at the desired angle, or pan the optic while glassing.

- To unlock the leveling head, rotate the Leveling Head Locking Knob clockwise (viewing from the top) until the leveling head moves freely. Adjust to your desired position and lock the leveling head.
- To lock the leveling head, rotate the Leveling Head Locking Knob counter-clockwise (viewing from the top) until you feel tension on the knob. Do not overtighten.



Rotate the Leveling Head Locking Knob to adjust position or lock in place.

Attaching Optics to Radian™ Leveling Head

The leveling head uses Arca-Swiss style quick-release plates. To mount your optic to the tripod:

1. Twist the Quick-Release Locking Knob counter-clockwise to remove the Quick-Release Plate.
2. Attach the plate to your optic. Be sure to tighten the Mount Bolt from the bottom side of the plate and flip the D-ring so it lies flat.
3. Place the Quick-Release Plate back into the tripod head and turn the Quick-Release Locking Knob clockwise to securely lock the plate in the head.

NOTE: To mount binoculars to the tripod, a binocular adapter is required. Purchase Vortex® binocular adapters from your local dealers.

NOTE: Some optics are designed to be Arca-Swiss compatible and can be mounted to the tripod head without the need for plates.

TIP: Purchase additional quick-release plates for your optics so it is easy for you to switch equipment.





VIP WARRANTY

OUR UNCONDITIONAL PROMISE TO YOU.

We promise to repair or replace the product. Absolutely free.

- ▶ **Unlimited**
- ▶ **Unconditional**
- ▶ **Lifetime Warranty**

service@VortexOptics.com • 800-426-0048

Note: The VIP Warranty does not cover loss, theft, deliberate damage, or cosmetic damage not affecting product performance.

For additional information, and the most up-to-date product manuals, visit VortexOptics.com



M-00297-0

© 2020 Vortex Optics

® Registered Trademark and TM Trademark of Vortex Optics.